JUPITER - C/E APP User Manual

Contents

JUPITER -C/E APP User Manual	1
1. APP download	3
1. Android download: Google Play	3
2. iOS download: APP Store	3
2. Account Registration/Login	3
1. Select Server	3
2. Register	4
3. Login	5
4. Forgot password	6
5. Account Management - Change Password/Logout/Logout	7
3. Add device	9
1. Add entry	9
2. Equipment List	11
4. Add process	12
1. Bluetooth added	12
2. Distribution network	14
3. Firmware upgrade	16
5. Communication methods between App and device	17
1. Bluetooth communication	17
2. MQTT communication (wifi standard)	17
6. Check equipment working data	19
1. Real-time working status	19

Marstek energy Co., Ltd.

2. Historical data	20
3. Working mode	22
7. Setting function	27
1. Distribution network	27
2. Language Settings	28
3. Shared equipment	29
4. User Feedback	
5. Statistics	31
6. APP version number	31
7. Device number	31
8. Restore factory settings	32

1. APP Download

- 1. Android download: Google Play
- 2. iOS download: APP Store

Download link:

https://eu.hamedata.com/ems/apk/marstek/index.html

QR code download :



2. Account Registration/Login

1. Select a server

Select the server corresponding to the region where the device is located, click the [OK] button after selection, and enter the login page. The upper right corner of the login page is the entrance to



switch servers, which can be clicked to change;

2. Registration

Enter your email address, verification code and password (length must be 8-30 bytes) as required; click the [Register] button to complete the registration. After successful registration, a prompt box will pop up indicating successful registration and the user will automatically return to the login page.



3. Login

Enter the registered email address and password, click the [Login] button, and the login is successful;

Note: The server selected in the upper right corner of the login page must be consistent with the server of the account you are logging in to. If you register an account under a certain server, select that

server to log in. Accounts on different servers cannot communicate with each other.

4. Forgot your password

There is a [Forgot Password] entry on the login page; enter your email address, verification code and new password (8-30 bytes), click the [Reset Password] button, and after the reset is successful, you can log in with the new password;



5. Account Management - Change Password/Log Out/Log Out

After successful login, jump to the homepage and click the [Settings] button in the upper right corner to enter the settings page; click the email address to enter the account management page, where you can perform the following operations on the account;



Change password: Enter the email address, original password and new password (8-30 bytes), click the [Change Password] button, and a message will pop up indicating that the password has been changed successfully. You can use the new password to log in next time.

Log out: Click [Sign out] to log out of your account. You will need to log in again the next time you enter the app.

Cancel account: Enter your email address and password, click the [Account Delection] button, and you will be prompted that your

account has been cancelled. The cancelled account cannot be logged in again and needs to be re-registered

Account management European Union	Account management European Union
@mailto.plus	@mailto.plus
*** Change Password	*** Change Password
→ Account deletion >	→ Account deletion >
	A Sign out >

\equiv Add a device

1. Add an entry

If the account has not added any device, there is an [Add Device]

Marstek energy Co., Ltd.

button in the upper left corner of the homepage;

If the account has added devices, there is a + button in the upper right corner of the device list. Both entrances can enter the device adding page;



2. Add method

The APP has two ways to add: [QR code] and [Bluetooth] ; QR code add : Scan the QR code on the device screen;



2. Equipment List

After binding the device, click the device name to go to the device list. One account can add multiple different devices;

JC >	k Device management
Pull to Refresh-Update at:2024-11-02 10:58	JC Mac:7ce712dabaa8
Image: Solar Power Ow OW OW OW P1 P2 P3 P4	uuu Mac:441a840497d6
 ⑦ Grid Power ● Battery ○ W 	AC Couple Mac:2419720d3a1e
Generation Today 0.0kwh >	62e5 Mac:e88da6f362e5
🗢 🔠 Work Mode 🛛 Manual 🗲	

4. Add a process

1. Add Bluetooth

Click Bluetooth Add to jump to the Bluetooth Add page; the list is the devices scanned by Bluetooth , click the device to be added, and after loading, jump to the naming page (the name is not recommended to be too long), enter the name and click the [Add Device] button, and the device is successfully bound;



 Add via Bluetooth 	K Enter a new device name
HM_SENSOR_be2 e 94:70:6C:CD:BE:2E -66.db	Enter a new device name
MST_ACCP_2970 24:19:77:0D:29:70 -53 db	You are activating a new device, and we will create a new space on the server for your device to store historical data. Click on" Add Device "to continue activating the device.
Bluetooth adding device, please wait! MST_ACCP_21ad 24:19:72:0D:21:AD -51 db	Add device
Tap to search again	

Note: When you enter the Bluetooth add page for the first time , a pop-up window for Bluetooth authorization may appear . You need to agree to the Bluetooth authorization (if no pop-up window appears, you can confirm that the Bluetooth of the app has been authorized in the phone settings) and turn on the Bluetooth switch of the phone ;

2. Network distribution

After the device is added successfully, jump to the configuration

webpage, and you need to configure the device under Bluetooth connection ; enter the wifi name (automatically fill in the wifi name connected to the mobile phone) and password, click [Begin Configuration], and the device can be connected to the Internet after the network configuration is successful;

 WiFi configuration 	JC >	\$
	Pull to Refresh-Update at:2024-11-02 11:03	
← Hame		
Password,8-30 characters		
It is recommended that wifi names and passwords are less than 32 bytes in length and do not contain special characters such as "!"	盛 Solar Power	Ow
"-", "_", spaces, etc. In The device can only use WiFi networks operating at the 2.4 GHz frequency.	ow ow ow	ow
	P1 P2 P3	P4
Begin Configuration	 Grid Power Batter 	ry
Skip	0w >	~
	Generation	3kWh 9 %
	Today 0.0kwh >	
	☆ Work Mode ◆	Manual >

Note: After adding a device, there will be a wifi logo on the device homepage. Click wifi under Bluetooth connection to re-configure the device.

3. Firmware Upgrade

After network configuration , if there is a new version of the firmware, there will be a pop-up window for upgrading. You can upgrade directly or click to cancel the next upgrade.



Update Firmware	Update Firmware
JC V113->V115	Update successful
Updating 0.0%	
It will take about 5 minutes	
\triangle Please keep the device powered on during the upgrade process.	
	Done

5. Communication method between App and

device

1. Bluetooth communication

Bluetooth icon is green: the app is communicating with the device via Bluetooth ;

Bluetooth is gray: the APP is disconnected from the device' s Bluetooth and Bluetooth communication is not possible ;

2. MQTT communication (wifi standard)

Bluetooth connection : Wi-Fi is green (device network is normal), Wi-Fi is gray (device network is disconnected) ;

Bluetooth is not connected: Wi-Fi is green (device MQTT is

communicating normally), Wi-Fi is gray (device MQTT is disconnected);

Note: If one of Bluetooth and WiFi is green, the app can



communicate with the device.

小阳台 >			\$
不下 <u>址</u> 时前- 见 前于2024-			
盛 光伏功率			Ow
ow	ow	ow	ow
P1	P2	P3	P4
⑦ 市电功率	>	■ 电池 (2.5)	3kwh
■ 发电量 今日 0.0kwh	>	Ļ	9%
	工作模式		手动模式 >

6. Check the equipment working data

1. Real-time working status

When the APP is communicating with the device, you can view the real-time working status of the device; the home page can show the device's photovoltaic power, mains power, cumulative power generation, battery power and working mode;

Note: After the APP loses communication with the device, the data of the last communication will be displayed by default, otherwise 0 will be displayed;



2. Historical data

Click [GRID Power] to view historical statistics, including daily

photovoltaic and discharge power and electricity;



Click [Power Generation] on the home page to see the amount of electricity generated by the device during operation ;



3. Working mode

Click on the working mode to enter the mode setting page; there are automatic and manual modes, and the automatic mode is selected by default;



Manual mode: Set 5 non-overlapping time periods. Click any time period to set the time, power and cycle. The switch is off by default. The setting takes effect when the switch is turned on.

〈 Discharge mode	Cancel OK
O Auto	Time 08:30 11:30
🥪 Manual	Power
08:30 11:30 /600W	600 /w
18:00 23:00 /600W	Please select a week!
00:00 00:00 /0W SUN MON TUE WED THU FRI SAT	SUN MON TUE WED THU FRI STA
00:00 00:00 /0W SUN MON TUE WED THU FRI SAT	
00:00 00:00 /0W SUN MON TUE WED THU FRI SAT	

Automatic mode : Select the automatic mode to switch to automatic mode. You can choose four different CT connections. The CT needs to be in the same network as the device. The connection process is as follows



〈 Discharge mode	〈 Discharge mode
🧭 Auto	Auto
Marstek CT001	Marstek CT001
Connecting to CT	CT connection successful
 Discharge:0W Phase A:0W Phase B:0W Phase C:0W 	Tip CT configuration successful! OK
O Manual	O Manual

After the connection is successful, you can see the working power of

the device under CT, and the data is updated every 5 seconds:

〈 Discharge mode	〈 Discharge mode
🧭 Auto	🧭 Auto
Marstek CT001	Marstek CT002 >
CT connection successful	CT connection successful
Discharge:793W Phase A:512W Phase B:108W Phase C:755W	 Discharge:800W Phase A:1749W Phase B:-479W Phase C:-80W
O Manual	O Manual

7. Setting function

1. Network distribution

Click here to configure the device. The configuration needs to be

done under Bluetooth connection ;



2. Language settings

There are 9 languages to switch between; if you choose to follow the system, the app will display the language in the phone settings;

Settings	۲	 Language Setting Please select language
WiFi configuration	>	Follow system
Language Setting	>	中文 ^{zh}
« Share device	>	English
User feedback	>	Deutsch ^{de}
Power	>	日本語 ^{ja}
Statistics	>	Español ^{es}
(i) App V:1.5.7	>	Français ^{fr}
Device : V61	>	Italiano ^{it}
C Restore factory settings	>	Nederlands ni
		POISKI ^{pl}
		Română

3. Share devices

You can share [View only permission] or [Share management] permissions;

[View-only permission] : The person being shared can only view the working status of the device and cannot change it;

[Share management privileges] : The person being shared can

change the working status of the device;

Settings	۲	Share device
WiFi configuration	>	Please enter the sharer's email
Hanguage Setting	>	
Share device	>	Device Name: ACCP-31A0
User feedback	>	Entitlement granted: View Only Permission Share management
Power	>	privileges
Statistics	>	
(i) App V:1.5.7	>	Share Now
Device : V61	>	
C Restore factory settings	>	

4. User Feedback

You can enter a content of less than 1,500 words, describe the problem and submit it. The after-sales staff will contact you as soon as possible .



5. Statistics

On the same device home page, you can view statistics

6. APP version number

Display the current version number of the APP

7. Device number

Displays the firmware version number. New means the latest

firmware package is available and can be upgraded .

No "New " means the latest version is already available and no upgrade is required.



8. Restore factory settings

Click Restore Factory Settings, a confirmation window will pop up, and the device will perform the factory reset operation after confirmation;

Settings	۲	Settings	۲
WiFi configuration	>	🗢 WiFi configuration	
Language Setting	>	Language Setting	
🗬 Share device	>	Share device	
User feedback	>	Tip	>
Power	>	Do you really want to reset device?	>
Statistics	>	Сапсеl	>
(i) App V:1.5.7	>	(i) App V:1.5.7	>
Device : V115 New	>	Device : V115 New	
C Restore factory settings	>	C Restore factory settings	